

■ Connector I/O signals

Terminal number	Signal name	Function
A-1	ABS-PT	Move the point from the origin position
B-1	INC-PT	Move the point from the current position
A-2	AUTO-R	Start automatic operation
B-2	STEP-R	Start step operation
A-3	ORG-S	Return to the origin
B-3	RESET	Reset
A-4	SERVO	Return to servo on
B-4	LOCK	Interlock
A-5	DI 0	General input 0
B-5	DI 1	General input 1
A-6	DI 2	General input 2
B-6	DI 3	General input 3
A-7	DI 4	General input 4
B-7	DI 5	General input 5
A-8	(SVCE)	Service mode input
B-8	DO 5	General output 5
A-9	DO 0	General output 0
B-9	DO 1	General output 1
A-10	DO 2	General output 2
B-10	DO 3	General output 3
A-11	DO 4	General output 4
B-11	END	End normal execution
A-12	BUSY	Executing the command
B-12	READY	Ready for operation
A-13	FG	Frame ground
B-13	FG	Frame ground
A-14	GND	Signal ground
B-14	GND	Signal ground
A-15	NC	Reserved (use inhibited)
B-15	NC	Reserved (use inhibited)
A-16	NC	Reserved (use inhibited)
B-16	NC	Reserved (use inhibited)
A-17	PA+	Feedback pulse output
B-17	PA-	Feedback pulse output
A-18	PB+	Feedback pulse output
B-18	PB-	Feedback pulse output
A-19	PZ+	Feedback pulse output
B-19	PZ-	Feedback pulse output
A-20	NC	Reserved (use inhibited)
B-20	NC	Reserved (use inhibited)

■ Pulse train I/O connector signals

Terminal number	Signal name	Function
A-1	NC	Reserved (use inhibited)
B-1	NC	Reserved (use inhibited)
A-2	NC	Reserved (use inhibited)
B-2	PCLR	Differential clear input
A-3	ORG-S	Return to the origin input
B-3	RESET	Alarm reset input
A-4	SERVO	Servo-ON input
B-4	INH	Command pulse inhibition input
A-5	DI 0	General input 0
B-5	DI 1	General input 1
A-6	DI 2	General input 2
B-6	DI 3	General input 3
A-7	DI 4	General input 4
B-7	DI 5	General input 5
A-8	NC	Reserved (use inhibited)
B-8	DO 5	General output 5
A-9	DO 0	General output 0
B-9	DO 1	General output 1
A-10	DO 2	General output 2
B-10	DO 3	General output 3
A-11	DO 4	General output 4
B-11	IN-POS	In-position output
A-12	SRDY	Servo ready output
B-12	ALM	Alarm output
A-13	FG	Frame ground
B-13	FG	Frame ground
A-14	GND	Signal ground
B-14	GND	Signal ground
A-15	PULS+	Command pulse input
B-15	PULS-	Command pulse input
A-16	DIR+	Command direction input
B-16	DIR-	Command direction input
A-17	PA+	Feedback pulse output
B-17	PA-	Feedback pulse output
A-18	PB+	Feedback pulse output
B-18	PB-	Feedback pulse output
A-19	PZ+	Feedback pulse output
B-19	PZ-	Feedback pulse output
A-20	NC	Reserved (use inhibited)
B-20	NC	Reserved (use inhibited)