

**SR1-X**

|                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>① Regenerative unit is needed if using in a perpendicular position and movement stroke is 700mm or more.</p> <p>② Regenerative unit is needed if using in a perpendicular position.</p> <p>③ Regenerative unit is needed if using in a perpendicular position, using at maximum speeds exceeding 1000mm per second, or if using high leads (40).</p> | <p>④ Regenerative unit is needed if using at maximum speeds exceeding 1000mm per second.</p> <p>⑤ Regenerative unit is needed if using at maximum speeds exceeding 1250mm per second.</p> <p>⑥ Regenerative unit is needed if using at maximum speeds exceeding 750mm per second.</p> |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**SR1-P**

|                   |                 |    | PHASER         |                  |                |                |              |                |                |                |                |
|-------------------|-----------------|----|----------------|------------------|----------------|----------------|--------------|----------------|----------------|----------------|----------------|
|                   |                 |    | MR16/<br>MR16D | MR16H/<br>MR16HD | MR20/<br>MR20D | MR25/<br>MR25D | MF7/<br>MF7D | MF15/<br>MF15D | MF20/<br>MF20D | MF30/<br>MF30D | MF75/<br>MF75D |
| Driver selection  | SR1-P           | 05 | ●              |                  |                |                |              |                |                |                |                |
|                   |                 | 10 |                | ●                |                | ●              | ●            | ●              | ●              |                |                |
|                   |                 | 20 |                |                  | ●              |                |              |                |                | ●              | ●              |
| Regenerative unit | No entry (None) |    | ●              | ●                | ●              | ●              | ●            | ●              |                |                |                |
|                   | R (RG1)         |    |                |                  |                |                |              |                | ●              | ●              |                |
|                   | R (RGU-2)       |    |                |                  |                |                |              |                |                |                | ●              |